

### Clean Catalyst System

ACTIVITY NO.	ACTIVITY	TICK WHEN COMPLETED
Priority	Put on Respirator as specified for spray painting, Protective Clothing, Eye Protection, and PVC Gloves.	
1	Disconnect the catalyst pump from the upper slave arm.	
1a	Pull out the top quick pin in the upper slave arm.	
1b	Pull up the piston rod priming knob and lean the top of the catalyst pump toward the resin pump as far as it will go.	
2	Empty any remaining catalyst from the catalyst jug.	
3	Fill the catalyst jug with clean distilled water.	
4	Slowly and gently pump the distilled water through the system by moving the catalyst pump-priming knob up and down by hand.	
5	Continue hand pumping until a stream of clean water flows from the gun on both the upstroke and downstroke.	
6	Empty the water from the catalyst jug and continue hand pumping until water no longer exits the gun.	
7	Blow, clean compressed air into the catalyst jug lines to remove moisture.	
8	Disable the catalyst pump by trapping the upper bearing block of catalyst pump between the vertical post and the quick pin.	

#### ABNORMAL CONDITIONS OBSERVED AND CORRECTED

Abnormal Condition	✓ when corrected

OPERATORS NAME: \_\_\_\_\_ DATE: \_\_\_\_\_

SIGN OFF WHEN SHUTDOWN CHECKS ARE COMPLETED : \_\_\_\_\_